

Scanned to PDF

5 November

2013

From paper

held by:

Norman Ryan

**TM 11-5820-358-34P**

---

**TECHNICAL MANUAL**

**DIRECT SUPPORT AND GENERAL SUPPORT MAINTENANCE**

**REPAIR PARTS AND SPECIAL TOOLS LISTS**

**RADIO RECEIVER R-390A/URR**

**5820-538-7555**

---

**HEADQUARTERS, DEPARTMENT OF THE ARMY**

**FEBRUARY 1972**

TECHNICAL MANUAL }  
 No. 11-5820-358-34P }

HEADQUARTERS  
 DEPARTMENT OF THE ARMY  
 WASHINGTON, D.C., 11 February 1972

**Direct Support and General Support Maintenance**  
**Repair Parts and Special Tools Lists**  
**RADIO RECEIVER R-390A/URR**  
**5820-538-7555**  
*Current as of 1 March 1971*

	Paragraph	Page
SECTION I. INTRODUCTION		
Scope .....	1	1
General .....	2	1
Explanation of columns .....	3	1
Special information .....	4	2.1
How to locate repair parts .....	5	2.1
Federal supply codes for manufacturers .....	6	2.1
Reporting of equipment publication improvements .....	7	2.1
II. REPAIR PARTS FOR DIRECT SUPPORT, GENERAL SUPPORT, AND DEPOT MAINTENANCE .....		4
III. SPECIAL TOOLS, TEST AND SUPPORT EQUIPMENT (NOT APPLICABLE)		
IV. INDEX—FEDERAL STOCK NUMBER AND REFERENCE NUMBER CROSS-REFERENCE TO FIGURE AND ITEM NUMBER .....		87
V. INDEX—REFERENCE DESIGNATION CROSS-REFERENCE TO PAGE NUMBER .....		118

**LIST OF ILLUSTRATIONS**

Number	Title	Page
1	Radio Receiver R-390A/URR .....	137
2	Radio Receiver R-390A/URR, top view .....	138
3	Radio Receiver R-390A/URR, bottom view .....	138
4	Unmodified IF. Subchassis, top view .....	139
5	IF. subchassis MOD I, Order No. 363-Phila-54 and all IF. subchassis on Order No. 14-Phila-56, top view .....	140
6	Unmodified IF. subchassis, bottom view, rear section .....	141
7	IF. subchassis, bottom view, front section .....	142
8	IF. subchassis, bottom view, front section .....	143
9	RF. subchassis, top view .....	144
10	RF. subchassis, bottom view, front section .....	145
11	RF. subchassis, bottom view, rear section .....	146
12	Crystal-oscillator subchassis, top view .....	147
13	Crystal-oscillator subchassis, bottom view .....	148
14	Crystal-oscillator subchassis, internal view of crystal oven .....	149
15	VFO subchassis, top view .....	149
16	VFO subchassis, bottom view .....	150
17	AF subchassis, top view .....	151
18	AF subchassis, bottom view .....	152
19	Power-supply subchassis, top view .....	153
20	Power-supply subchassis, bottom view .....	154
21	Antenna relay assembly, internal view .....	155
22	Radio Receiver R-390A/URR, front panel and interior of main frame .....	156
23	RF. gear train assembly, location of parts .....	157
24	Location of RF bandswitch shaft clamp, detent spring, and ten-turn stops .....	158
25	Oldham coupler details .....	159

\*This manual supersedes TM 11-5820-358-35P, 20 March 1962, including all changes.